CHECKLIST

Fire Door Closer Adjustment Checklist

- [ ] Locate the latching-speed valve on the closer body
- [ ] Turn the valve clockwise by a quarter turn
- [ ] Open the door fully and let it close on its own
- [ ] Confirm the door latches securely without bouncing
- [ ] Adjust the main closing-speed valve if slamming continues
- [ ] Test the door from different starting positions
- [ ] Check that intumescent strips are intact and aligned
- [ ] Record which valves you adjusted and by how much
- [ ] Inspect the closer for leaks or visible damage
- [ ] Retest the door after a week of use