CHECKLIST

Drop seal installation and maintenance checklist

- [ ] Measure the door width and order a seal at least as wide as the opening
- [ ] Mark the position so the deployed seal contacts the floor evenly
- [ ] Rout the housing groove to the exact depth and width specified
- [ ] Fix the housing securely and align the trigger with the frame
- [ ] Adjust the seal height until the blade makes firm contact without dragging
- [ ] Test the door through several cycles and check for smooth operation
- [ ] Inspect the seal every six months for wear, damage and proper deployment
- [ ] Clean the blade and housing, removing grit that could jam the mechanism
- [ ] Replace the blade when it no longer touches the floor or shows visible wear
- [ ] Record each inspection and any repairs in your fire-safety log