CHECKLIST

Intumescent strip fitting checklist

- [ ] Confirm the strip type matches the door's certification
- [ ] Measure and mark groove positions accurately before routing
- [ ] Rout grooves to the exact depth and width specified
- [ ] Cut strip lengths square without stretching the material
- [ ] Press strip into groove without twisting or compressing
- [ ] Space fixings as the manufacturer directs
- [ ] Check the gap is consistent when the door closes
- [ ] Never paint over the strip or fill the groove beforehand
- [ ] Inspect the strip regularly for damage or detachment
- [ ] Keep a record of the product used for compliance purposes