CHECKLIST

Fire Exit Door Measuring Checklist

- [ ] Measure width at the top, middle and bottom of the opening
- [ ] Use the smallest width figure as the working measurement
- [ ] Measure height at both jambs and the centre
- [ ] Measure to the finished floor level, not the bare subfloor
- [ ] Record wall or frame depth at several points along the opening
- [ ] Check the full swing arc for obstructions on both sides
- [ ] Note any threshold seal or drop seal clearance needed
- [ ] Write all figures down together before ordering
- [ ] Have measurements checked before a door leaf is cut